


DIGI-SHOT M



Waterproof camera bag with flap and zip



- Carrying handle
- Abrasion resistant Cordura
- Waterproof zipper
- Fixing for shoulder strap
- Flap with quick release
- Mesh pockets (on both sides) with Velcro
- Stable bottom
- Removable padded shoulder strap



main compartment



- Loop for opening of zipper
- Belt loops



Application example for Digi-Shot M: DSLR camera with zoom lens, two further lenses, battery and memory card (contents not included)

Size	Height cm/in.	Width cm/in.	Depth cm/in.	Vol. l/cu.in.	Weight g/oz.
M	18.5/	23.5/9.3	13.5/5.3	5.9360	721/25.4

- Stable waterproof shoulder bag for extensive camera equipment
 - Reliable protection of rain and spray
 - Main compartment with waterproof zip
 - Two lateral outer mesh pockets (not waterproof) with Velcro
 - Quick release buckles on flap allow quick access to main compartment
 - PU-coated Cordura fabric
 - Carrying handle
 - Flexible, individually adjustable pads
 - Internal mesh pockets (not waterproof) inside flap for memory cards, filter, batteries etc.
 - Padded, removable shoulder strap fixed with snap hooks
 - Features of size M: D-rings for fixing the ORTLIEB camera carrying system (optional accessory art. code P15)
 - Size M suitable for larger SLR cameras with zoom lens and two further lenses (wide angle to standard)
- Bag is supplied with shoulder strap

PRODUCT-INFO

Please find information on IP symbols on our info sheet or at www.ortlieb.com/ip-symbols

Digi-Shot_M_12_2012

DIGI-SHOT L



Waterproof camera bag with flap and zip



- Carrying handle
- Abrasion resistant Cordura
- Waterproof zipper
- Fixing for shoulder strap
- Flap with quick release
- Mesh pockets (on both sides) with Velcro
- Loops for fixing tripod
- Stable bottom
- Removable padded shoulder strap



- Loop for opening of zipper
- Belt loops



Application example for Digi-Shot L: DSLR camera with zoom lens, one further housing, three further lenses, battery and memory card (contents not included)

Size	Height cm/in.	Width cm/in.	Depth cm/in.	Vol. l/cu.in.	Weight g/oz.
L	22.5/8.9	27.5/10.8	17.5/6.9	10.8/659	921/32.4

- Large, stable waterproof shoulder bag for extensive camera equipment
- Reliable protection of rain and spray
- Main compartment with waterproof zip
- Two lateral outer mesh pockets (not waterproof) with Velcro
- Quick release buckles on flap allow quick access to main compartment
- PU-coated Cordura fabric
- Carrying handle
- Flexible, individually adjustable pads
- Inner mesh pockets (not waterproof) inside flap for memory cards, filter, batteries etc.
- Padded, removable shoulder strap fixed with snap hooks
- Features size L only: inner pockets in main compartment lid, loops for fixing tripod
- Size M suitable for larger SLR cameras with zoom lens and two further lenses (wide angle to standard)

Bag is supplied with shoulder strap

PRODUCT-INFO

Please find information on IP symbols on our info sheet or at www.ortlieb.com/ip-symbols

Digi_Shot_L_12_2012